

Jump Start System

1. Turn off ignition and all accessories, put vehicle in Park, set emergency brake
2. Make sure Jump Start System is OFF.
3. Remove booster clamps from protective holsters, squeeze and pull down.
4. Connect positive (+) red clamp to battery's positive terminal.
5. Connect negative (-) black clamp to chassis or a solid non-moving metal vehicle component. If audible alarm sounds, polarity is not correct, reverse the connections.

**DO NOT TURN ON SAFETY SWITCH
WITH ALARM SOUNDING**

6. Turn Jump Start System's power ON.
7. Start vehicle (do not crank for more than 5-6 seconds).
8. After vehicle starts, turn jump start system OFF, disconnect negative (-) black cable followed by the positive (+) red cable, and return to holsters.
9. Return the jump start system to the library.

Reviewed by the Board of Trustees

April 18, 2006